

## Moyer Process & Control Company

105 North Wayne Street / PO Box 935

Fremont Indiana 46737

260/495-2405 Fax 260/495-1290

[info@moyercompanies.com](mailto:info@moyercompanies.com)

### Rebirthing the Eurgage

--Plug in gage.

--Press and hold the "mode" and "4" key and turn power on. Continue holding for a few seconds, then release. This is Hardware Test Mode.

--Move cursor up and down to make sure it works. Turn the sort and adjust knobs back and forth while watching the screen. Make sure the numbers for the SORT, ADJUST and PROBE are changing. Turn off.

--Press and hold the "Mode" key and turn gage on. Release after you see the SETUP Screen come up. DON'T PANIC. The screen may look a little funny.

--Move the cursor through each option and toggle. At the options where data is entered, clear it all out and re-enter the information.

--Change the screen to the CONFIGURE by moving the cursor to "CONFIGURE" and press "ENT".

--Do the same in the CONFIGURE screen as in the SETUP screen. Move the cursor thru each option and toggle. At options where data is entered, clear it all out and re-enter the information.

--When done, turn the power off. The gage is now ready to be setup and used.

Please contact Moyer at 260/495-2405 if you have any questions or problems.