

Moyer Process & Control Co Inc
105 N Wayne St / PO Box 935
Fremont IN 46737
260/495-2405 fax 260/495-1290
info@moyercompanies.com

Initializing the Merlin Gage

- Make sure gage is turned off and power cord is plugged in.
- Press and hold the "4" key and turn the power on. Continue holding for a few seconds longer, then release. This is Hardware Test Mode.
- Move the cursor up and down to make sure it works. Turn the sort and adjust knobs back and forth while watching the screen. Make sure the numbers for the SORT, ADJUST, and PROBE are changing. Turn power off.
- Press and hold the "SETUP" key and turn the power on. Release after you see the SETUP screen come up. DON'T PANIC. The screen may look a little funny. This is the Setup Mode.
- Move the cursor through each option and toggle. At the options where data is entered, clear it all out and re-enter the information.
- Change to the "CONFIG" screen and the "STAT" screen by pressing their key and do the same as in the setup screen. Turn power off when finished.
- The gage is now ready to be setup and used.